

PY_ML_ATaCR_Comp

August 23, 2023

```
[ ]: def mat2df(files):  
    '''  
    Converts all loaded matlab variables into a single dataframe  
    '''  
    if not isinstance(files,list):  
        files = [files]  
    files = sorted(files)  
    out = []  
    df = pd.DataFrame()  
    FNUM = 0  
    for f in files:  
        df2 = pd.DataFrame()  
        cfold = f[0:maxstrfind(f,'/')+1]  
        cf = f[maxstrfind(f,'/')+1:len(f)]  
        mat = spio.loadmat(f, simplify_cells=True)  
        matvars = list(mat.keys())[3:len(list(mat.keys()))]  
        oldkey = list(mat.keys())[-1] #Replaces Last Key with a single_  
↳hardcoded name. Assumes a single variable (ie one struct) was saved to the_  
↳matfile  
        for k in range(3): #pop out the first three keys. they are_  
↳artifacts from the mat import  
            mat.pop(list(mat.keys())[0])  
        for k in matvars:  
            if isinstance(mat[k],list):  
                for dct in mat[k]:  
                    tmp = pd.DataFrame.  
↳from_dict(dct,orient='index').T  
                    tmp['FNUM'] = FNUM  
                    df2 = pd.concat([df2,tmp])  
                mat[k] = df2  
            else:  
                mat[k] = pd.DataFrame.from_dict(mat[k]).T  
                mat[k]['FNUM'] = FNUM  
        if len(matvars)>1:  
            for i in range(len(matvars)-1):  
                mat[matvars[0]] = pd.  
↳merge(mat[matvars[0]],mat[matvars[i+1]],on='FNUM')
```

```

                                # display(mat[matvars[0]])
    fdf = mat[matvars[0]].set_index('FNUM')
    fdf['Folder'] = cfold
    fdf['File'] = cf
    out.append(fdf)
    FNUM += 1

    for d in out:
        df = pd.concat([df,d])
        df = df.groupby('FNUM',as_index=False,dropna=False).ffill().
        ↳groupby('FNUM',as_index=False,dropna=False).bfill() #<---Fills data gaps
        ↳using adjacent rows from only the same file.
        df = df.sort_values('File')
        return df
def maxstrfind(s,p):
    """
    Wild this doesnt exist in Python libraries. Finds LAST occurence of
    ↳expression in a string.
    """
    i = 0
    while i>-1:
        io = i
        i = s.find(p,i+1,len(s))
    return io
def datenum_to_datetime64(dnum):
    """
    Just some Matlab DateNum nonsense
    """
    days = np.asarray(dnum) - 719529 # shift to unix epoch (1970-01-01)
    return np.round((days * 86400000)).astype("datetime64[ms]")
def ClosestMLPreEventTF(tfdir,event_time):
    """
    Replicates the ML ATaCR method for defining the 'nearest' TF to an
    ↳event. It is a slightly different method than the Python version.
    """
    files = g.glob(tfdir + '/*.mat')
    files = [ele for ele in files if '_AVERAGE_' not in ele] #<---Remove the
    ↳station average from file list
    eventids = np.array(list(map(int,[f.split('/')[1].split('_')[1] for f
    ↳in files]))) #<Split file strings down to their event ids. Assumes format
    ↳dir/stuff_EVENTID_stuff
    f = files[np.where(((np.array(event_time,dtype=int) - eventids)>0) &
    ↳((np.array(event_time,dtype=int) - eventids)==np.min((np.
    ↳array(event_time,dtype=int) - eventids))))[0][0]]
    out = mat2df(f)
    return out
def organize_evdata(evdata):

```

```

'''
    Builds ObsPy trace objects inside the dataframes from the imported
↳ Matlab data
'''

itr1 = (evdata['channel'].squeeze().str.find('1')>0)
itr2 = (evdata['channel'].squeeze().str.find('2')>0)
itrZ = (evdata['channel'].squeeze().str.find('Z')>0)
itrP = ~((evdata['channel'].squeeze().str.find('1')>0) +
↳ (evdata['channel'].squeeze().str.find('2')>0) + (evdata['channel'].squeeze().
↳ str.find('Z')>0))

tmp = evdata[itr1]
tr1 = Trace(data=tmp['data'].squeeze())
tr1.stats.sampling_rate = tmp.sampleRate.squeeze()
tr1.stats.network = tmp.network.squeeze()
tr1.stats.station = tmp.station.squeeze()
tr1.stats.channel = tmp.channel.squeeze()
tr1.stats.starttime = UTCDateTime( datenum_to_datetime64(tmp.startTime.
↳ squeeze()).tolist().strftime('%Y-%m-%dT%H:%M:%S.%f') )

tmp = evdata[itr2]
tr2 = Trace(data=tmp['data'].squeeze())
tr2.stats.sampling_rate = tmp.sampleRate.squeeze()
tr2.stats.network = tmp.network.squeeze()
tr2.stats.station = tmp.station.squeeze()
tr2.stats.channel = tmp.channel.squeeze()
tr2.stats.starttime = UTCDateTime( datenum_to_datetime64(tmp.startTime.
↳ squeeze()).tolist().strftime('%Y-%m-%dT%H:%M:%S.%f') )

tmp = evdata[itrZ]
trZ = Trace(data=tmp['data'].squeeze())
trZ.stats.sampling_rate = tmp.sampleRate.squeeze()
trZ.stats.network = tmp.network.squeeze()
trZ.stats.station = tmp.station.squeeze()
trZ.stats.channel = tmp.channel.squeeze()
trZ.stats.starttime = UTCDateTime( datenum_to_datetime64(tmp.startTime.
↳ squeeze()).tolist().strftime('%Y-%m-%dT%H:%M:%S.%f') )

tmp = evdata[itrP]
trP = Trace(data=tmp['data'].squeeze())
trP.stats.sampling_rate = tmp.sampleRate.squeeze()
trP.stats.network = tmp.network.squeeze()
trP.stats.station = tmp.station.squeeze()
trP.stats.channel = tmp.channel.squeeze()
trP.stats.starttime = UTCDateTime( datenum_to_datetime64(tmp.startTime.
↳ squeeze()).tolist().strftime('%Y-%m-%dT%H:%M:%S.%f') )

evdata = evdata.assign(Trace=0)
evdata.iat[np.squeeze(np.where(itr1)).tolist(), -1] = tr1
evdata.iat[np.squeeze(np.where(itr2)).tolist(), -1] = tr2
evdata.iat[np.squeeze(np.where(itrZ)).tolist(), -1] = trZ

```

```

        evdata.iat[np.squeeze(np.where(itrP)).tolist(), -1] = trP
        evdata.tr1 = tr1
        evdata.tr2 = tr2
        evdata.trZ = trZ
        evdata.trP = trP
        return evdata
def
    ↪GetML_EventData_and_TransferFunctions(event_time,network,sta,ml_preprocevent_folder,
    ↪= 'ML_PreProcEventData'):
        folder = ATaCR_ML_DataFolder[ml_preprocevent_folder]
        path = folder + '/' + event_time + '/*.mat'
        ml_files = g.glob(path)
        evdata = mat2df(ml_files)
        evdata = evdata[(evdata['network']==network)&(evdata['station']==sta)]
        evdata = organize_evdata(evdata)
        folder = ATaCR_ML_DataFolder['ML_CorrectedTraces']
        path = folder + '/' + network + '/' + sta + '/' + network + sta + '_' +
    ↪str(event_time) + '_corrseis' + '.mat'
        ml_files = g.glob(path)
        corrected_evdata = mat2df(ml_files)
        corrected_evdata =
    ↪corrected_evdata[(corrected_evdata['network']==network)&(corrected_evdata['station']==sta)]
        corrected_evdata = corrected_evdata.assign(Trace=0)
        for i in range(len(corrected_evdata)):
            tmp = corrected_evdata.iloc[i]
            tr = Trace(data=tmp['timeseries'].squeeze())
            tr.stats.sampling_rate = 1/tmp['dt']
            tr.stats.network = tmp['network']
            tr.stats.station = tmp['station']
            tr.stats.channel = tmp['label']
            tr.stats.starttime = evdata.trZ.stats.starttime
            corrected_evdata.iat[i, -1] = tr
        ftf = ATaCR_ML_DataFolder['ML_TransferFunctions'] + '/' + network + '/' +
    ↪sta
        ml_tf = ClosestMLPreEventTF(ftf,event_time)
        return evdata,corrected_evdata,ml_tf
def ML_fig_event_corrected(PreProcEvent,CorrectedEvent,evstream=None,
    ↪TF_list=None, fmin=1./150., fmax=2.,prefix =
    ↪'',yes_filter=True,ylo=0,yhi=1,scale='linear',yhard=None):
    """
        Adapted from Python ATaCR code. Refactored for efficiency with a few
    ↪more options. -CH-8/17/23

        Function to plot the corrected vertical component seismograms.

        Parameters

```

```

-----
evstream : :class:`~obtsools.classes.EventStream`
           Container for the event stream data
Tf_list : list
           List of Dictionary elements of transfer functions used
           for plotting the corrected vertical component.

"""
keys = ['Z1', 'Z2-1', 'ZP-21', 'ZH', 'ZP-H', 'ZP']
# Unpack vertical trace and filter
preproc_itr1 = np.where((PreProcEvent['channel'].squeeze().str.
↳find('1')>0))[0][0]
preproc_itr2 = np.where((PreProcEvent['channel'].squeeze().str.
↳find('2')>0))[0][0]
preproc_itrZ = np.where((PreProcEvent['channel'].squeeze().str.
↳find('Z')>0))[0][0]
preproc_itrP = np.where(~((PreProcEvent['channel'].squeeze().str.
↳find('1')>0) + (PreProcEvent['channel'].squeeze().str.find('2')>0) +
↳(PreProcEvent['channel'].squeeze().str.find('Z')>0)))[0][0]
trZ = PreProcEvent.iloc[preproc_itrZ]['Trace']
trZ.filter(
    'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
↳zerophase=True)
sr = trZ.stats.sampling_rate
taxis = np.arange(0., trZ.stats.npts/sr, 1./sr)
if ylon:
    yl = [-1e-4, 1e-4]
if yhard is not None:
    yl = yhard

plt.figure(figsize=(8, 8))

# plt.subplot(611)
# plt.plot(taxis, trZ.data, 'lightgray', lw=0.5)
# plt.yscale(scale)
eventtime = CorrectedEvent.eventid.squeeze().to_list()[0]
evtstamp = str(UTCDateTime(eventtime).year) + '.' +
↳str(UTCDateTime(eventtime).julday) + '.' + str(UTCDateTime(eventtime).hour)
↳+ '.' + str(UTCDateTime(eventtime).minute)
i = 611
for key in keys:
    plt.subplot(i)
    if scale=='symlog':
        plt.plot(taxis, np.abs(trZ.data), 'lightgray', lw=0.5)
    else:
        plt.plot(taxis, trZ.data, 'lightgray', lw=0.5)

```

```

        plt.yscale(scale)
        if TF_list[key]:
            Corrtrace = CorrectedEvent.iloc[np.
↳where(~CorrectedEvent.label.squeeze().str.find(key))[0][0]]
            tr = Trace(data=Corrtrace['Trace'].
↳data,header=Corrtrace['Trace'].stats)
            if yes_filter:
                tr = tr.filter('bandpass', freqmin=fmin,
↳freqmax=fmax, corners=2, zerophase=True)
            if scale=='symlog':
                plt.plot(taxis, np.abs(tr.data), 'k', lw=0.5)
                plt.plot(taxis, np.abs(tr.data), 'k', lw=0.5)
            else:
                plt.plot(taxis, tr.data, 'k', lw=0.5)
                plt.plot(taxis, tr.data, 'k', lw=0.5)
            plt.yscale(scale)
            plt.title(prefix + Corrtrace.network + '.' + Corrtrace.station
↳+ ' ' + evtstamp + ': ' + key, fontdict={'fontsize': 8})
            if scale=='linear':
                plt.gca().ticklabel_format(axis='y', style='sci',
↳useOffset=True,scilimits=(-3, 3))
            plt.xlim((0., trZ.stats.npts/sr))
            if ylon:
                plt.ylim(yl)
            if yhard is not None:
                plt.ylim(yl)
            i+=1
        plt.xlabel('Time since earthquake (sec)')
        plt.tight_layout()

    return plt

def Py_fig_event_corrected(evstream, TF_list, fmin=1./150., fmax=2.,prefix=''):
    """
    Adapted ATaCR plot code with a few more options for versatility - CH-8/
↳15/23

    Function to plot the corrected vertical component seismograms.

    Parameters
    -----
    evstream : :class:`~obtsools.classes.EventStream`
        Container for the event stream data
    Tf_list : list
        List of Dictionary elements of transfer functions used
        for plotting the corrected vertical component.

```

```

"""

# Unpack vertical trace and filter
trZ = evstream.trZ.copy()
trZ.filter(
    'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
    zerophase=True)
sr = trZ.stats.sampling_rate
taxis = np.arange(0., trZ.stats.npts/sr, 1./sr)

plt.figure(figsize=(8, 8))

plt.subplot(611)
plt.plot(
    taxis, trZ.data, 'lightgray', lw=0.5)
if TF_list['Z1']:
    tr = Trace(
        data=evstream.correct['Z1'],
        header=trZ.stats).filter(
            'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
            zerophase=True)
    plt.plot(taxis, tr.data, 'k', lw=0.5)
plt.title(prefix + evstream.key + ' ' + evstream.tstamp +
    ': Z1', fontdict={'fontsize': 8})
plt.gca().ticklabel_format(axis='y', style='sci', useOffset=True,
    scilimits=(-3, 3))
plt.xlim((0., trZ.stats.npts/sr))

plt.subplot(612)
plt.plot(
    taxis, trZ.data, 'lightgray', lw=0.5)
if TF_list['Z2-1']:
    tr = Trace(
        data=evstream.correct['Z2-1'],
        header=trZ.stats).filter(
            'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
            zerophase=True)
    plt.plot(taxis, tr.data, 'k', lw=0.5)
plt.title(prefix + evstream.tstamp + ' : Z2-1', fontdict={'fontsize': 8})
plt.gca().ticklabel_format(axis='y', style='sci', useOffset=True,
    scilimits=(-3, 3))
plt.xlim((0., trZ.stats.npts/sr))

plt.subplot(613)
plt.plot(
    taxis, trZ.data, 'lightgray', lw=0.5)

```

```

    if TF_list['ZP-21']:
        tr = Trace(
            data=evstream.correct['ZP-21'],
            header=trZ.stats).filter(
                'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
↪zerophase=True)
        plt.plot(taxis, tr.data, 'k', lw=0.5)
        plt.title(prefix + evstream.tstamp + ': ZP-21', fontdict={'fontsize': 8})
↪8})
        plt.gca().ticklabel_format(axis='y', style='sci', useOffset=True,
                                   scilimits=(-3, 3))
        plt.xlim((0., trZ.stats.npts/sr))

    plt.subplot(614)
    plt.plot(
        taxis, trZ.data, 'lightgray', lw=0.5)
    if TF_list['ZH']:
        tr = Trace(
            data=evstream.correct['ZH'],
            header=trZ.stats).filter(
                'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
↪zerophase=True)
        plt.plot(taxis, tr.data, 'k', lw=0.5)
        plt.title(prefix + evstream.tstamp + ': ZH', fontdict={'fontsize': 8})
        plt.gca().ticklabel_format(axis='y', style='sci', useOffset=True,
                                   scilimits=(-3, 3))
        plt.xlim((0., trZ.stats.npts/sr))

    plt.subplot(615)
    plt.plot(
        taxis, trZ.data, 'lightgray', lw=0.5)
    if TF_list['ZP-H']:
        tr = Trace(
            data=evstream.correct['ZP-H'],
            header=trZ.stats).filter(
                'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
↪zerophase=True)
        plt.plot(taxis, tr.data, 'k', lw=0.5)
        plt.title(prefix + evstream.tstamp + ': ZP-H', fontdict={'fontsize': 8})
        plt.gca().ticklabel_format(axis='y', style='sci', useOffset=True,
                                   scilimits=(-3, 3))
        plt.xlim((0., trZ.stats.npts/sr))

    plt.subplot(616)
    plt.plot(
        taxis, trZ.data, 'lightgray', lw=0.5)
    if TF_list['ZP']:

```



```

        tr = Trace(
            data=evstream.correct['ZP'],
            header=trZ.stats).filter(
                'bandpass', freqmin=fmin, freqmax=fmax, corners=2,
↪zerophase=True)
        plt.plot(taxis, tr.data, 'k', lw=0.5)
        plt.title(prefix + evstream.tstamp + ': ZP', fontdict={'fontsize': 8})
        plt.gca().ticklabel_format(axis='y', style='sci', useOffset=True,
                                   scilimits=(-3, 3))
        plt.xlim((0., trZ.stats.npts/sr))

        plt.xlabel('Time since earthquake (sec)')
        plt.tight_layout()
        return plt
def TraceDelta(event_time, network, sta, respct=False, scale='linear'):
    '''Just writes residuals to the obspy trace objects to feed into
↪ML_fig_event_corrected'''
    PreProcEvent, CorrectedEvent, ML_TFs =
↪GetML_EventData_and_TransferFunctions(event_time, network, sta)
    for i in range(len(PreProcEvent)):
        tmp = PreProcEvent.iloc[i]['Trace']
        tmp.data = tmp.data*0
        # PreProcEvent.iloc[i]['Trace'] = tmp
        PreProcEvent.iat[i,-1] = tmp
    ML_CorrectedEvent = CorrectedEvent
    path = ATaCR_Py_DataFolder['Py_CorrectedTraces'] + '/' + network + '.'
↪+ sta + '/CORRECTED/' + network + '.' + sta + '.' + eventtime_jdaystr + '.'
↪day'
    py_files = g.glob(path + '*.pkl')
    f = py_files[0]
    # display(f)
    evstream = pkl.load(open(f, 'rb'))
    keys = CorrectedEvent['label'].to_list()
    delta = pd.DataFrame.from_dict({'label':keys, 'residual':[PreProcEvent.
↪iloc[0]['data']*0 for i in range(len(keys))])})
    for k in keys:
        PyTr = evstream.correct[k]
        MLTr = CorrectedEvent.iloc[(CorrectedEvent['label']==k).
↪to_list()].timeseries.to_list()[0]
        if respct:
            res = ((PyTr - MLTr)/MLTr)
        else:
            res = PyTr - MLTr
        i = np.where(delta['label']==k)[0][0]
        delta.at[i, 'residual'] = res
        tmp = CorrectedEvent.iloc[i,-1]

```

```

        tmp.data = delta.at[i,'residual']
        CorrectedEvent.iloc[i,-1] = tmp
        prefix = '<Py-ML Residual Fraction>'
        ML_fig_event_corrected(PreProcEvent,CorrectedEvent,evstream=None,
↪TF_list=TF_list, fmin=1./150., fmax=2.
↪,prefix=prefix,yes_filter=False,yton=False,scale=scale)

```

1 MATLAB vs Python Versions of ATaCR

1. —

Filtering
dis-
agree-
ment
during
event
correction—

– 1. A
lowpass
filter &
taper is
per-
formed
on the
transfer
func-
tions in
b4_CorrectEvent
that is
not
present
any-
where
in the
Python
version.

2. —

Averaging
choice
for de-
riving
TFs—

– 1. By
default,
both
codes
use the
transfer
func-
tions
made
from
the
DAY
AVER-
AGE
preced-
ing the
event
time.

1. That
said,
the pre-
event
time
window
that
deter-
mines
this TF
selec-
tion is
very
slightly
differ-
ent in
the two
codes.

The
ML
version
requires
both
start
and
end

3. —

Choosing
the pre-
event
TF—

1.
Unlike
the
Matlab
version,
there is
nothing
in the
Python
code to
stop
individ-
ual
trace
data
(SAC
files) to
be less
than an
entire
day of
record-
ing.
Thus
an edge
case
exist
when
query-
ing
times
from
IRIS to
yield
hour
long
traces
(ie
many
deploy-
ments
retain
SAC
files in
hour

4.

—Tilt
Search-
ing for
H—

1. Both codes use the same tilt frequency range $([.005, .035])$ when determining maximum coherence.

5. —

Filter
differences—

– 1. In
the
Python
version,
station
spectra
at
every
level of
pro-
cessing
(ie
quality
control
at lines
232 and
276 of
at-
acr_clean_spectra
and at-
acr_clean_spectra,
respec-
tively)
has a
SIG-
NIFI-
CANTLY
higher
corner
([0.004
2.0]
Hz)
than
the
Matlab
version
([0.004
0.2]
Hz).

6. —

Hanning
Taper
Inconsistency—

– 8.
The
han-
ning
taper
appears
to be
more
than
twice
as long
in the
Python
version
com-
pared
to Mat-
lab's.
Admit-
tedly,
its
possible
ML's
han-
ning
might
operate
differ-
ently
than
Numpy's,
han-
ning(2x_num_pts_to_overlap),
but I
would
doubt
it based
on the
docu-
menta-
tion for
them.
1. Fur-
ther-
more,
the

7. —

Inconsistencies
in
power
spectra
station
averages—

– 1.
While
they
are
station
aver-
ages
and not
used
for de-
riving
the TFs
(by de-
fault),
their is
marked
incon-
sisten-
cies in
power
and fq
when
com-
paring
the two
code
out-
puts.
As
stated
above,
the
band-
pass for
Python
is
signifi-
cantly
wider
and al-
though
this
alone

8. —
 —In
 final
 product
 comparisons—
 —
 – 1.
 The
 cor-
 rected
 event
 traces
 seem
 nearly
 identi-
 cal in
 nearly
 all
 cases
 looked
 seen so
 far.

```
[ ]: import obstools
from obstools.atacr import DayNoise, TFNoise, EventStream, StaNoise, utils
import obstools.atacr.plotting as atplot
from pathlib import Path
from obspy.core import read, Stream, Trace, AttribDict, UTCDateTime
import scipy.io as spio
import os
import glob as g
import matplotlib.pyplot as plt
import pandas as pd
import numpy as np
from IPython.display import display
import pickle as pkl
from obstools.atacr import utils
from obspy import Trace
import pickle
import os, fnmatch
from obstools.atacr.plotting import fig_QC, fig_average, fig_av_cross,
↳fig_coh_ph, fig_TF, fig_comply, fig_event_raw, fig_event_corrected
```

```
[ ]: # Important Directories
CompFolder = '/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp'
```

```

ATaCR_ML_DataFolder = dict()
ATaCR_ML_DataFolder['ML_ATaCR_Parent'] = CompFolder + '/ATaCR'
ATaCR_ML_DataFolder['ML_DataParentFolder'] = CompFolder + '/ATaCR/DATA'
ATaCR_ML_DataFolder['ML_RawDayData'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/datacache_day'
ATaCR_ML_DataFolder['ML_PreProcDayData'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/datacache_day_preproc'
ATaCR_ML_DataFolder['ML_RawEventData'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/datacache_event'
ATaCR_ML_DataFolder['ML_PreProcEventData'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/datacache_event_preproc'
ATaCR_ML_DataFolder['ML_StaSpecAvg'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/noisetc/AVG_STA'
ATaCR_ML_DataFolder['ML_CorrectedTraces'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/noisetc/CORRSEIS'
ATaCR_ML_DataFolder['ML_b1b2_StaSpectra'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/noisetc/SPECTRA'
ATaCR_ML_DataFolder['ML_TransferFunctions'] = _
    ↳ ATaCR_ML_DataFolder['ML_DataParentFolder'] + '/noisetc/TRANSFUN'

ATaCR_Py_DataFolder = dict()
ATaCR_Py_DataFolder['Py_DataParentFolder'] = CompFolder + '/ATaCR_Python'
ATaCR_Py_DataFolder['Py_RawDayData'] = _
    ↳ ATaCR_Py_DataFolder['Py_DataParentFolder'] + '/Data'
# ATaCR_Py_DataFolder['Py_PreProcDayData']
# ATaCR_Py_DataFolder['Py_RawEventData']
# ATaCR_Py_DataFolder['Py_PreProcEventData']
ATaCR_Py_DataFolder['Py_StaSpecAvg'] = _
    ↳ ATaCR_Py_DataFolder['Py_DataParentFolder'] + '/AVG_STA'
ATaCR_Py_DataFolder['Py_CorrectedTraces'] = _
    ↳ ATaCR_Py_DataFolder['Py_DataParentFolder'] + '/EVENTS'
ATaCR_Py_DataFolder['Py_b1b2_StaSpectra'] = _
    ↳ ATaCR_Py_DataFolder['Py_DataParentFolder'] + '/SPECTRA'
ATaCR_Py_DataFolder['Py_TransferFunctions'] = _
    ↳ ATaCR_Py_DataFolder['Py_DataParentFolder'] + '/TF_STA'

sps = 5
network = '7D'
stalist = ['M01A', 'M02A', 'M07A', 'M08A']
event_time = '201203090709'
eventtime_jdaystr = str(UTCDateTime(event_time).year) + '.' + _
    ↳ str(UTCDateTime(event_time).julday).zfill(3) + '.' + _
    ↳ str(UTCDateTime(event_time).hour).zfill(2) + '.' + _
    ↳ str(UTCDateTime(event_time).minute).zfill(2)
# files = g.glob(ATaCR_ML_DataFolder['ML_RawDayData'] + '/' + network + '/' + _
    ↳ sta + '/*.mat')

```

```

# files = g.glob(ATaCR_ML_DataFolder['ML_PreProcDayData'] + '/' + network + '/' +
    ↪ sta + '/*.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_RawEventData'] + '/' + event_time + '/'
    ↪ *.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_PreProcEventData'] + '/' + event_time +
    ↪ '/' + *.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_StaSpecAvg'] + '/*.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_CorrectedTraces'] + '/' + network + '/'
    ↪ ' + sta + '/*.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_b1b2_StaSpectra'] + '/' + network + '/'
    ↪ ' + sta + '/b1/*.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_b1b2_StaSpectra'] + '/' + network + '/'
    ↪ ' + sta + '/b2/*.mat')
# files = g.glob(ATaCR_ML_DataFolder['ML_TransferFunctions'] + '/' + network +
    ↪ '/' + sta + '/*.mat')

```

```

[ ]: for stai in stalist:
    # Matlab ATaCR output plot
    prefix = '<Matlab-ATaCR-Output> '
    ml_preprocevent_folder = 'ML_PreProcEventData'
    PreProcEvent, CorrectedEvent, ML_TFs =
    ↪ GetML_EventData_and_TransferFunctions(event_time, network, stai, ml_preprocevent_folder,
    ↪ ml_preprocevent_folder)
    if stai == 'M02A':
        ylon = False
        yhard = [-0.2 * np.mean(np.array(PreProcEvent['data'].to_list())), 0.2 * np.
        ↪ mean(PreProcEvent['data'].to_list())]
    else:
        ylon = True
        yhard = None
    TF_list = {i : j for i, j in zip(CorrectedEvent.label.to_list(), np.
    ↪ ones(len(CorrectedEvent.label.to_list()), dtype=bool))}
    ML_fig_event_corrected(PreProcEvent, CorrectedEvent, evstream=None,
    ↪ TF_list=TF_list, fmin=1./150., fmax=2., prefix=prefix, ylon = ylon, yhard =
    ↪ yhard)

    # Python ATaCR output plot
    path = ATaCR_Py_DataFolder['Py_CorrectedTraces'] + '/' + network + '.' +
    ↪ stai + '/CORRECTED/' + network + '.' + stai + '.' + eventtime_jdaystr + '.'
    ↪ day'
    py_files = g.glob(path + '*.pkl')
    f = py_files[0]
    display(f)
    evstream = pickle.load(open(f, 'rb'))
    TF_list = {i : j for i, j in zip(list(evstream.correct.keys()), np.
    ↪ ones(len(list(evstream.correct.keys())), dtype=bool))}

```


```


prefix = '<Python-ATaCR-Output> '
Py_fig_event_corrected(evstream, TF_list, prefix=prefix)
# Residual plot
TraceDelta(event_time, network, stai, respct=True, scale='symlog')
plt.show()


print('-----')
print('-----')

```


'/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/EVENTS/7D.M01A/
 ↳CORRECTED/7D.M01A.2012.069.07.09.day.pkl'










'/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/EVENTS/7D.M02A/
 CORRECTED/7D.M02A.2012.069.07.09.day.pkl'










'/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/EVENTS/7D.M07A/
 CORRECTED/7D.M07A.2012.069.07.09.day.pkl'









'/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/EVENTS/7D.M08A/
 CORRECTED/7D.M08A.2012.069.07.09.day.pkl'







```
obstools.atacr.plotting.fig_event_corrected(evstream, TF_list, fmin=0.006666666666666667,
fmax=2.0)
```

Function to plot the corrected vertical component seismograms.

Parameters : evstream (EventStream) – Container for the event stream data

Tf_list (list) – List of Dictionary elements of transfer functions used for plotting the corrected vertical component.

```

[ ]: k = 'ML_StaSpecAvg'
# k = 'ML_b1b2_StaSpectra'
# folder = ATaCR_ML_DataFolder[k] + '/' + network + '/' + stai + '/b1'
# folder = ATaCR_ML_DataFolder[k] + '/' + network + '/' + stai + '/b2'
# ml_files = g.glob(folder + '/*.mat')
# print('Matlab-ATaCR Files: ' + str(len(ml_files)))
# display(ml_files)

for stai in stalist:
    folder = ATaCR_ML_DataFolder[k]
    if k=='ML_b1b2_StaSpectra':
        folder = ATaCR_ML_DataFolder[k] + '/' + network + '/' + stai + '/b1'
        folder = ATaCR_ML_DataFolder[k] + '/' + network + '/' + stai + '/b2'
    ml_files = g.glob(folder + '/*.mat')
    d = mat2df(ml_files)
    if k=='ML_StaSpecAvg':
        d = d[((d['network']==network)) & (d['station']==stai)].iloc[0]
        power = obstools.atacr.classes.Power(c11=np.atleast_2d(np.array(np.
↪array(d.c11_mean.tolist()))).T,c22=np.atleast_2d(np.array(np.array(d.
↪c22_mean.tolist()))).T,cZZ=np.atleast_2d(np.array(np.array(d.czz_mean.
↪tolist()))).T,cPP=np.atleast_2d(np.array(np.array(d.cpp_mean.tolist()))).T)
    else:
        d = d[((d['network']==network)) & (d['station']==stai)]
        power = obstools.atacr.classes.Power(c11=np.atleast_2d(np.array(np.
↪array(d.c11_stack.tolist()))).T,c22=np.atleast_2d(np.array(np.array(d.
↪c22_stack.tolist()))).T,cZZ=np.atleast_2d(np.array(np.array(d.czz_stack.
↪tolist()))).T,cPP=np.atleast_2d(np.array(np.array(d.cpp_stack.tolist()))).T)
    # display(d)
    ncomp = 4
    # Spectral Average of ML-ATaCR Data
    f = np.array(list(d.f))
    print('File Chosen: ' + d.File)

    if k=='ML_StaSpecAvg':
        print('Days Used: ' )
        display(list(d.daysused))

    key = 'Matlab_ATaCR - Station-AVERAGE ' + (d.File)
    gooddays = np.array([True],dtype=bool)
    fig_QC(f, power, gooddays, ncomp, key)
    plt.show()
# -----

folder = ATaCR_Py_DataFolder['Py_StaSpecAvg']
path = folder + '/' + network + '.' + stai + '/'
py_files = g.glob(path + '*.pkl')

```



```

# print('Python-ATaCR Files: ' + str(len(py_files)))
display(py_files)
f = py_files[0]
# print('File Chosen: ' + f)
# display('Dates used are encoded into the file name: ')
# print(f.split('/')[-1])
file = open(f, 'rb')
pydata = pickle.load(file)
fq = pydata.f
gooddays = np.array([True], dtype=bool)
ncomp = 4
key = 'Python ATaCR - Station-AVERAGE ' + network + '.' + stai
power = pydata.power
c11=np.atleast_2d(power.c11).T
c22=np.atleast_2d(power.c22).T
cZZ=np.atleast_2d(power.cZZ).T
cPP=np.atleast_2d(power.cPP).T
fig_QC(fq, obstools.atacr.classes.Power(c11=c11, c22=c22, cZZ=cZZ,
↪cPP=cPP), gooddays, ncomp, key)
plt.show()

```


File Chosen: 7D_M01A_b2_spectraavg.mat

Days Used:


```

[{'id': '201203010000'},
 {'id': '201203020000'},
 {'id': '201203030000'},
 {'id': '201203040000'},
 {'id': '201203050000'},
 {'id': '201203060000'},
 {'id': '201203070000'},
 {'id': '201203080000'},
 {'id': '201203090000'}]

```




```
[ '/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/AVG_STA/7D.M01A/
↳ 2012.061-2012.070.avg_sta.pkl ']
```




File Chosen: 7D_M02A_b2_spectraavg.mat

Days Used:

```
[{'id': '201203010000'},
 {'id': '201203020000'},
 {'id': '201203030000'},
 {'id': '201203040000'},
 {'id': '201203060000'},
 {'id': '201203070000'},
 {'id': '201203080000'},
 {'id': '201203080000'},
 {'id': '201203090000'}]
```




```
[ '/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/AVG_STA/7D.M02A/
↳ 2012.061-2012.070.avg_sta.pkl ']
```




File Chosen: 7D_M07A_b2_spectraavg.mat

Days Used:

```
[{'id': nan},
 {'id': '201203020000'},
 {'id': '201203030000'},
 {'id': '201203040000'},
 {'id': '201203050000'},
 {'id': '201203060000'},
 {'id': '201203070000'},
 {'id': '201203080000'},
 {'id': '201203090000'}]
```




```
[ '/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/AVG_STA/7D.M07A/
↳ 2012.061-2012.070.avg_sta.pkl ']
```



File Chosen: 7D_M08A_b2_spectraavg.mat

Days Used:

```
[{'id': '201203010000'},
 {'id': '201203020000'},
 {'id': '201203030000'},
 {'id': '201203040000'},
 {'id': '201203050000'},
 {'id': '201203060000'},
 {'id': '201203070000'},
 {'id': '201203080000'},
 {'id': '201203090000'}]
```



```
[ '/Users/charlesh/Documents/Codes/ATaCR/ATaCR_Comp/ATaCR_Python/AVG_STA/7D.M08A/
↳ 2012.061-2012.070.avg_sta.pkl ']
```